



# CLORODOSER® TIMER QUICK SET UP INSTRUCTIONS

These instructions are for a single program to dispense the same amount at the same time each day.

Refer to the standard instructions for other programming options.

1. To delete all programs and time press the small "R" button at the bottom center of the timer face.
2. Set the time first. Slide the **RUN** switch at the top right of the timer to the left, towards the clock symbol.
3. Press the **1...7** button under the timer display window to move the small black triangle in the display, positioning it under the current day of the week. These are indicated by the numbers 1 through 7 just above the display window. Monday is number 1, Sunday is 7.
4. Next press the **H** button to set the current hour of the day. Note there is also an AM or PM indication in the display.
5. Next press the **M** button to set the current minute of the hour.
6. Setting the program. Slide the **RUN** switch to the right towards the circled **P**.
7. Press the **1...7** button repeatedly until a black triangle is displayed under every day of the week. This will operate the CloroDoser every day. For individual days, just set a lit triangle under the day you want to dispense.
8. Use the **H** and the **M** buttons to set the time of the day the CloroDoser should start dispensing. Make sure the correct AM or PM timing is set.
9. Press the circled **P** button located under the left side of the display window. This locks in the "On Time", referred to as program #1 and advances the display to program #2, the "Off Time".
10. Once again, press the **1...7** button repeatedly until a black triangle is displayed under every day of the week. **This is very important.** The CloroDoser must shut off every day that it is scheduled to turn on or excess product will be pumped. If you selected only one day for dispensing, select the same day for the off time.
11. The CloroDoser will dispense 3 ½ ounces of product each minute. Determine the amount of product that will be used each time, divide by 3 ½, and that will be the number of minutes to run the CloroDoser
12. Use the **H** and **M** buttons to set the time for the CloroDoser to shut off. Make sure AM or PM corresponds to program #1. Example: If the CloroDoser is set to turn on at 12 AM, midnight, and you want to dispense 7 ounces, set the off time, to 12:02 AM.
13. Again, press the circled **P** button to lock in the off time.
14. Slide the **RUN** switch back to the centermost position. Programming is complete.
15. Make sure the **AUTO** switch at the top left of the timer is also in the centermost position. If this switch is to the **O** position on the right, the CloroDoser will not dispense at any time. If it is moved to the **I** position on the left, the dispenser will run continuously. Use this position for priming the circuit.